



# CS-TBR-85

## Тонер Cactus CS-TBR-85

| Бренд   | Наименование товара | Совместимость |
|---------|---------------------|---------------|
| Brother |                     | HL-1110R      |
| Brother |                     | HL-1111R      |
| Brother |                     | HL-1112R      |
| Brother |                     | HL-1210WR     |
| Brother |                     | HL-1212WR     |
| Brother |                     | HL-1118R      |
| Brother |                     | HL-2030R      |
| Brother |                     | HL-2035R      |
| Brother |                     | HL-2040R      |
| Brother |                     | HL-2070NR     |

| <b>Бренд</b> | <b>Наименование товара</b> | <b>Совместимость</b> |
|--------------|----------------------------|----------------------|
| Brother      |                            | HL-2130R             |
| Brother      |                            | HL-2132R             |
| Brother      |                            | HL-2140R             |
| Brother      |                            | HL-2142R             |
| Brother      |                            | HL-2150NR            |
| Brother      |                            | HL-2170WR            |
| Brother      |                            | HL-2200R             |
| Brother      |                            | HL-2210R             |
| Brother      |                            | HL-2235R             |
| Brother      |                            | HL-2225R             |
| Brother      |                            | HL-2230R             |
| Brother      |                            | HL-2240R             |
| Brother      |                            | HL-2240DR            |

| <b>Бренд</b> | <b>Наименование товара</b> | <b>Совместимость</b> |
|--------------|----------------------------|----------------------|
| Brother      |                            | HL-2250DNR           |
| Brother      |                            | HL-2260R             |
| Brother      |                            | HL-2270R             |
| Brother      |                            | HL-L2300DR           |
| Brother      |                            | HL-L2340DWR          |
| Brother      |                            | HL-2365DWR           |
| Brother      |                            | HL-L2360DNR          |
| Brother      |                            | HL-L2380             |
| Brother      |                            | DCP-1510R            |
| Brother      |                            | DCP-1512R            |
| Brother      |                            | DCP-1610WR           |
| Brother      |                            | DCP-1612WR           |
| Brother      |                            | DCP-1910W            |

| <b>Бренд</b> | <b>Наименование товара</b> | <b>Совместимость</b> |
|--------------|----------------------------|----------------------|
| Brother      |                            | DCP-L2500DR          |
| Brother      |                            | DCP-L2520DWR         |
| Brother      |                            | DCP-L2540DWR         |
| Brother      |                            | DCP-L2560DWR         |
| Brother      |                            | DCP-7010R            |
| Brother      |                            | DCP-7020             |
| Brother      |                            | DCP-7025R            |
| Brother      |                            | DCP-7030R            |
| Brother      |                            | DCP-7032R            |
| Brother      |                            | DCP-7040R            |
| Brother      |                            | DCP-7045NR           |
| Brother      |                            | DCP-7055R            |
| Brother      |                            | DCP-7057R            |

| <b>Бренд</b> | <b>Наименование товара</b> | <b>Совместимость</b> |
|--------------|----------------------------|----------------------|
| Brother      |                            | DCP-7060DR           |
| Brother      |                            | DCP-7065DNR          |
| Brother      |                            | DCP-7070DWR          |
| Brother      |                            | DCP-7075WR           |
| Brother      |                            | MFC-1810R            |
| Brother      |                            | MFC-1815R            |
| Brother      |                            | MFC-1912WR           |
| Brother      |                            | MFC-L2700DWR         |
| Brother      |                            | MFC-L2720DWR         |
| Brother      |                            | MFC-L2740DWR         |
| Brother      |                            | MFC-2700DNR          |
| Brother      |                            | MFC-4800             |
| Brother      |                            | MFC-6800             |

| <b>Бренд</b> | <b>Наименование товара</b> | <b>Совместимость</b> |
|--------------|----------------------------|----------------------|
| Brother      |                            | MFC-7220             |
| Brother      |                            | MFC-7225             |
| Brother      |                            | MFC-7320R            |
| Brother      |                            | MFC-7360NR           |
| Brother      |                            | MFC-7420             |
| Brother      |                            | MFC-7440NR           |
| Brother      |                            | MFC-7820             |
| Brother      |                            | MFC-7840WR           |
| Brother      |                            | MFC-7860DWR          |
| Brother      |                            | MFC-9030             |
| Brother      |                            | MFC-9070             |
| Brother      |                            | MFC-9160             |
| Brother      |                            | MFC-9180             |

| <b>Бренд</b> | <b>Наименование товара</b> | <b>Совместимость</b> |
|--------------|----------------------------|----------------------|
| Brother      |                            | FAX-2820R            |
| Brother      |                            | FAX-2825R            |
| Brother      |                            | FAX-2845R            |
| Brother      |                            | FAX-2850             |
| Brother      |                            | FAX-2920R            |
| Brother      |                            | FAX-2940R            |
| Brother      |                            | FAX-2990R            |
| Brother      |                            | FAX-8070P            |
| Brother      |                            | IntelliFAX-2800      |
| Brother      |                            | IntelliFAX-2900      |
| Brother      |                            | IntelliFAX-3800      |