mage not found or type unkr

## mage not bund or type unknown CS-TBR-140

## **Тонер Cactus CS-ТВR-140**

Бренд	Наименование товара	Совместимость
Brother	HL	1030
Brother	HL	1110R
Brother	HL	1111R
Brother	HL	1112R
Brother	HL	1210WR
Brother	HL	1212WR
Brother	HL	1230
Brother	HL	1240
Brother	HL	1250
Brother	HL	1260E

Бренд	Наименование товара	Совместимость
Brother	HL	1270N
Brother	HL	1430
Brother	HL	1440
Brother	HL	1450
Brother	HL	1470N
Brother	HL	1650
Brother	HL	1670N
Brother	HL	1850
Brother	HL	1870N
Brother	HL	2030R
Brother	HL	2040R
Brother	HL	2070NR
Brother	HL	2130R

_	2035R
_	2132R
	2140R
_	2142R
_	2150NR
_	2170WR
_	2200R
_	2210R
_	2225R
_	2230R
_	2235R
_	2240R
_	2240DR

Бренд	Наименование товара	Совместимость
Brother	HL	2250DNR
Brother	HL	2260R
Brother	HL	2270R
Brother	HL	5030
Brother	HL	5040
Brother	HL	5050
Brother	HL	5070
Brother	HL	5130
Brother	HL	5140
Brother	HL	5140D
Brother	HL	5150D
Brother	HL	5170DN
Brother	HL	5240

Бренд	Наименование товара	Совместимость
Brother	HL	5250DN
Brother	HL	5270DN
Brother	HL	5280DW
Brother	HL	5340D
Brother	HL	5350DN
Brother	HL	5370DW
Brother	HL	5380DN
Brother	HL	5440D
Brother	HL	5450DN
Brother	HL	5450DNT
Brother	HL	5470DW
Brother	HL	6180DW
Brother	HL	6180DWT

Бренд	Наименование товара	Совместимость
Brother	HL	7010R
Brother	HL	7020
Brother	HL	7025R
Brother	HL	L2340DR
Brother	HL	L2340DWR
Brother	HL	L2360DNR
Brother	HL	L2365DWR
Brother	HL	L2380
Brother	HL	L5000D
Brother	HL	L5100DN
Brother	HL	L5100DNT
Brother	HL	L5200DW
Brother	HL	L6250DN

Бренд	Наименование товара	Совместимость
Brother	HL	L6300DN
Brother	HL	L6300DWT
Brother	HL	L6400DW
Brother	HL	L6400DWT
Brother	DCP	1510R
Brother	DCP	1512R
Brother	DCP	1610WR
Brother	DCP	1612WR
Brother	DCP	1910W
Brother	DCP	6600DW
Brother	DCP	7010R
Brother	DCP	7020
Brother	DCP	7025R

Brother         DCP         7030R           Brother         DCP         7032R           Brother         DCP         7040R           Brother         DCP         7045NR           Brother         DCP         7055R           Brother         DCP         7060DR           Brother         DCP         7065DNR           Brother         DCP         7070DWR           Brother         DCP         7075WR           Brother         DCP         8020           Brother         DCP         8025D	Бренд	Наименование товара	Совместимость
Brother         DCP         7040R           Brother         DCP         7045NR           Brother         DCP         7055R           Brother         DCP         7057R           Brother         DCP         7060DR           Brother         DCP         7065DNR           Brother         DCP         7070DWR           Brother         DCP         7075WR           Brother         DCP         8020	Brother	DCP	7030R
Brother         DCP         7045NR           Brother         DCP         7055R           Brother         DCP         7057R           Brother         DCP         7060DR           Brother         DCP         7065DNR           Brother         DCP         7070DWR           Brother         DCP         7075WR           Brother         DCP         8020	Brother	DCP	7032R
BrotherDCP7055RBrotherDCP7057RBrotherDCP7060DRBrotherDCP7065DNRBrotherDCP7070DWRBrotherDCP7075WRBrotherDCP8020	Brother	DCP	7040R
BrotherDCP7057RBrotherDCP7060DRBrotherDCP7065DNRBrotherDCP7070DWRBrotherDCP7075WRBrotherDCP8020	Brother	DCP	7045NR
BrotherDCP7060DRBrotherDCP7065DNRBrotherDCP7070DWRBrotherDCP7075WRBrotherDCP8020	Brother	DCP	7055R
BrotherDCP7065DNRBrotherDCP7070DWRBrotherDCP7075WRBrotherDCP8020	Brother	DCP	7057R
BrotherDCP7070DWRBrotherDCP7075WRBrotherDCP8020	Brother	DCP	7060DR
Brother DCP 7075WR  Brother DCP 8020	Brother	DCP	7065DNR
Brother DCP 8020	Brother	DCP	7070DWR
	Brother	DCP	7075WR
Brother DCP 8025D	Brother	DCP	8020
	Brother	DCP	8025D
Brother DCP 8025DN	Brother	DCP	8025DN

Бренд	Наименование товара	Совместимость
Brother	DCP	8040D
Brother	DCP	8045D
Brother	DCP	8045DN
Brother	DCP	8060
Brother	DCP	8065DN
Brother	DCP	80710D
Brother	DCP	8085DN
Brother	DCP	8110
Brother	DCP	8250
Brother	DCP	L2500DR
Brother	DCP	L2520DWR
Brother	DCP	L2540DWR
Brother	DCP	L2560DWR

Бренд	Наименование товара	Совместимость
Brother	DCP	L5500DN
Brother	MFC	1810R
Brother	MFC	1815R
Brother	MFC	1912WR
Brother	MFC	4800
Brother	MFC	6800
Brother	MFC	6800DW
Brother	MFC	6800DWT
Brother	MFC	6900DW
Brother	MFC	6900DWT
Brother	MFC	7220
Brother	MFC	7225
Brother	MFC	7420

Бренд	Наименование товара	Совместимость
Brother	MFC	7820
Brother	MFC	7320R
Brother	MFC	7360NR
Brother	MFC	7440NR
Brother	MFC	7840WR
Brother	MFC	7860DWR
Brother	MFC	8220
Brother	MFC	8350
Brother	MFC	8370DN
Brother	MFC	8420
Brother	MFC	
Brother	MFC	8440D
Brother	MFC	8440DN

Бренд	Наименование товара	Совместимость
Brother	MFC	8460N
Brother	MFC	8510DN
Brother	MFC	8520DN
Brother	MFC	8710DN
Brother	MFC	8750
Brother	MFC	8820D
Brother	MFC	8820DN
Brother	MFC	8840DN
Brother	MFC	8860DN
Brother	MFC	8870DW
Brother	MFC	8880DN
Brother	MFC	8890DN
Brother	MFC	8910DN

Бренд	Наименование товара	Совместимость
Brother	MFC	8950DW
Brother	MFC	9030
Brother	MFC	9070
Brother	MFC	9160
Brother	MFC	9180
Brother	MFC	9600
Brother	MFC	9650
Brother	MFC	9660
Brother	MFC	9750
Brother	MFC	9760
Brother	MFC	9850
Brother	MFC	9860
Brother	MFC	9870

Бренд	Наименование товара	Совместимость
Brother	MFC	9880
Brother	MFC	L2700DWR
Brother	MFC	L2720DWR
Brother	MFC	L2740DWR
Brother	MFC	2700DNR
Brother	MFC	L5700DN
Brother	MFC	L5750DW
Brother	MFC	L6800DW
Brother	MFC	L6800DWT
Brother	MFC	L6900DW
Brother	MFC	L6900DWT
Brother	FAX	2820R
Brother	FAX	2825R

Бренд	Наименование товара	Совместимость
Brother	FAX	2845R
Brother	FAX	2850
Brother	FAX	2920R
Brother	FAX	2940R
Brother	FAX	2990R
Brother	FAX	4750
Brother	FAX	5750
Brother	FAX	8070P
Brother	FAX	8350P
Brother	FAX	8360P
Brother	FAX	8750P
Brother	INTELLIFAX	2800
Brother	INTELLIFAX	2900

Бренд	Наименование товара	Совместимость
Brother	INTELLIFAX	3800
Brother	INTELLIFAX	4100