



# CS-TSG1-120

## Тонер Cactus CS-TSG1-120

Бренд	Принтер	Картридж	Ресурс	Вес заправки	Примечание
Lexmark	Lexmark Optra E310	13T0101	6000	200	
Lexmark	Lexmark Optra E312	13T0101	6000	200	
Lexmark	Lexmark Optra E312L	13T0101	6000	200	
Ricoh	Ricoh SP100	407059 SP101E	2000	80	
Ricoh	Ricoh SP100SF	407059 SP101E	2000	80	
Ricoh	Ricoh SP100U	407059 SP101E	2000	80	
Ricoh	Ricoh SP111	407442 SP110E	2000	80	
Ricoh	Ricoh SP111SF	407442 SP110E	2000	80	
Ricoh	Ricoh SP111SU	407442 SP110E	2000	80	
Ricoh	Ricoh SP150	408010 SP150HE	1500	60	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Ricoh	Ricoh SP150SP	408010 SP150HE	1500	60	
Ricoh	Ricoh SP150SU	408010 SP150HE	1500	60	
Ricoh	Ricoh SP150SUw	408010 SP150HE	1500	60	
Ricoh	Ricoh SP150w	408010 SP150HE	1500	60	
Ricoh	Ricoh SP200	407262 SP200HE	2600	90	
Ricoh	Ricoh SP200N	407262 SP200HE	2600	90	
Ricoh	Ricoh SP200Nw	407262 SP200HE	2600	90	
Ricoh	Ricoh SP200S	407262 SP200HE	2600	90	
Ricoh	Ricoh SP201N	407262 SP200HE	2600	90	
Ricoh	Ricoh SP202S	407262 SP200HE	2600	90	
Ricoh	Ricoh SP202SN	407262 SP200HE	2600	90	
Ricoh	Ricoh SP203F	407262 SP200HE	2600	90	
Ricoh	Ricoh SP203SFN	407262 SP200HE	2600	90	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Ricoh	Ricoh SP204SFN	407262 SP200HE	2600	90	
Ricoh	Ricoh SP204SN	407262 SP200HE	2600	90	
Ricoh	Ricoh SP204SN	407262 SP200HE	2600	90	
Ricoh	Ricoh SP210	407262 SP200HE	2600	90	
Ricoh	Ricoh SP210SF	407262 SP200HE	2600	90	
Ricoh	Ricoh SP210SU	407262 SP200HE	2600	90	
Ricoh	Ricoh SP211SU	407999 SP201E	1000	40	
Ricoh	Ricoh SP211SU	407254 SP201HE	2600	90	
Ricoh	Ricoh SP212Nw	407262 SP200HE	2600	90	
Ricoh	Ricoh SP212SFNw	407262 SP200HE	2600	90	
Ricoh	Ricoh SP212SFw	407262 SP200HE	2600	90	
Ricoh	Ricoh SP212SUw	407262 SP200HE	2600	90	
Ricoh	Ricoh SP212w	407262 SP200HE	2600	90	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Ricoh	Ricoh SP213FNw	407262 SP200HE	2600	90	
Ricoh	Ricoh SP220Nw	407999 SP201E	1000	40	
Ricoh	Ricoh SP220Nw	407254 SP201HE	2600	90	
Ricoh	Ricoh SP220SFNw	407999 SP201E	1000	40	
Ricoh	Ricoh SP220SFNw	407254 SP201HE	2600	90	
Ricoh	Ricoh SP220SNw	407254 SP201HE	2600	90	
Ricoh	Ricoh SP220SNw	407999 SP201E	1000	40	
Ricoh	Ricoh SP230DNw	408294 SP230H	3000	100	
Ricoh	Ricoh SP230SFNw	408294 SP230H	3000	100	
Ricoh	Ricoh SP277FNwX	408160 SP277HE	2600	90	
Ricoh	Ricoh SP277NwX	408160 SP277HE	2600	90	
Ricoh	Ricoh SP277SNwX	408160 SP277HE	2600	90	
Ricoh	Ricoh SP311DN	407246 SP311HE	3500	115	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Ricoh	Ricoh SP311DN	821242 SP311UHE	6400	210	
Ricoh	Ricoh SP311DNw	821242 SP311UHE	6400	210	
Ricoh	Ricoh SP311DNw	407246 SP311HE	3500	115	
Ricoh	Ricoh SP311SFN	407246 SP311HE	3500	115	
Ricoh	Ricoh SP311SFN	821242 SP311UHE	6400	210	
Ricoh	Ricoh SP311SFNw	821242 SP311UHE	6400	210	
Ricoh	Ricoh SP311SFNw	407246 SP311HE	3500	115	
Ricoh	Ricoh SP325DNw	407246 SP311HE	3500	115	
Ricoh	Ricoh SP325DNw	821242 SP311UHE	6400	210	
Ricoh	Ricoh SP325SFNw	821242 SP311UHE	6400	210	
Ricoh	Ricoh SP325SFNw	407246 SP311HE	3500	115	
Ricoh	Ricoh SP325SNw	407246 SP311HE	3500	115	
Ricoh	Ricoh SP325SNw	821242 SP311UHE	6400	210	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Ricoh	Ricoh SP330DN	408278 SP330L	3500	115	
Ricoh	Ricoh SP330DN	408281 SP330H	7000	230	
Ricoh	Ricoh SP330SFN	408281 SP330H	7000	230	
Ricoh	Ricoh SP330SFN	408278 SP330L	3500	115	
Ricoh	Ricoh SP330SN	408281 SP330H	7000	230	
Ricoh	Ricoh SP330SN	408278 SP330L	3500	115	
Ricoh	Ricoh SP377	408162 SP377XE	6400	210	
Ricoh	Ricoh SP377DNwX	408162 SP377XE	6400	210	
Ricoh	Ricoh SP377SFNwX	408162 SP377XE	6400	210	
Ricoh	Ricoh SP400DN	408061 SP400LE	5000	160	
Ricoh	Ricoh SP450DN	408061 SP400LE	5000	160	
Ricoh	Ricoh SP450DN	408060 SP400HE	10000	330	
Ricoh	Ricoh SPSFNw	407262 SP200HE	2600	90	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Samsung	Samsung ML- 1651	ML-1650D8	8000	260	
Samsung	Samsung ML-1010	ML-1210D3	3000	100	
Samsung	Samsung ML-1020M	ML-1210D3	3000	100	
Samsung	Samsung ML-1210	ML-1210D3	3000	100	
Samsung	Samsung ML-1220M	ML-1210D3	3000	100	
Samsung	Samsung ML-1250	ML-1210D3	3000	100	
Samsung	Samsung ML-1430	ML-1210D3	3000	100	
Samsung	Samsung ML-1440	ML-6060D6	6000	200	
Samsung	Samsung ML-1450	ML-6060D6	6000	200	
Samsung	Samsung ML-1500	ML-1710D3	3000	100	
Samsung	Samsung ML-1510	ML-1710D3	3000	100	
Samsung	Samsung ML-1510B	ML-1710D3	3000	100	
Samsung	Samsung ML-1520	ML-1710D3	3000	100	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Samsung	Samsung ML-1520	ML-1520D3	3000	100	
Samsung	Samsung ML-1520P	ML-1520D3	3000	100	
Samsung	Samsung ML-1610	ML-1610D3	3000	100	
Samsung	Samsung ML-1615	ML-1610D3	3000	100	
Samsung	Samsung ML-1630	ML-D1630A	2000	80	
Samsung	Samsung ML-1650	ML-1650D8	8000	260	
Samsung	Samsung ML-1710	ML-1710D3	3000	100	
Samsung	Samsung ML-1710B	ML-1710D3	3000	100	
Samsung	Samsung ML-1710D	ML-1710D3	3000	100	
Samsung	Samsung ML-1710P	ML-1710D3	3000	100	
Samsung	Samsung ML-1750	ML-1710D3	3000	100	
Samsung	Samsung ML-2010	ML-2010D3	3000	100	
Samsung	Samsung ML-2010	ML-1610D3	3000	100	



<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Samsung	Samsung ML-2015	ML-1610D3	3000	100	
Samsung	Samsung ML-2015	ML-2010D3	3000	100	
Samsung	Samsung ML-2020	ML-2010D3	3000	100	
Samsung	Samsung ML-2250	ML-2250D5	5000	160	
Samsung	Samsung ML-2250	ML-2550DA	10000	330	
Samsung	Samsung ML-2251n	ML-2550DA	10000	330	
Samsung	Samsung ML-2251n	ML-2250D5	5000	160	
Samsung	Samsung ML-2251np	ML-2250D5	5000	160	
Samsung	Samsung ML-2252w	ML-2250D5	5000	160	
Samsung	Samsung ML-2252w	ML-2550DA	10000	330	
Samsung	Samsung ML-2510	ML-1610D3	3000	100	
Samsung	Samsung ML-2510	ML-2010D3	3000	100	
Samsung	Samsung ML-2570	ML-2010D3	3000	100	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Samsung	Samsung ML-2571	ML-2010D3	3000	100	
Samsung	Samsung ML-2850d	ML-2850A	2000	80	
Samsung	Samsung ML-2850d	ML-2850B	5000	160	
Samsung	Samsung ML-2850nd	ML-2850B	5000	160	
Samsung	Samsung ML-2850nd	ML-2850A	2000	80	
Samsung	Samsung ML-3050	ML-D3050A	4000	130	
Samsung	Samsung ML-3050	ML-D3050B	8000	260	
Samsung	Samsung ML-3051	ML-D3050B	8000	260	
Samsung	Samsung ML-3051	ML-D3050A	4000	130	
Samsung	Samsung ML-3051n	ML-D3050A	4000	130	
Samsung	Samsung ML-3051n	ML-D3050B	8000	260	
Samsung	Samsung ML-3051nd	ML-D3050B	8000	260	
Samsung	Samsung ML-3051nd	ML-D3050A	4000	130	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Samsung	Samsung ML-3470d	ML-D3470A	4000	130	
Samsung	Samsung ML-3470d	ML-D3470B	10000	330	
Samsung	Samsung ML-3471nd	ML-D3470B	10000	330	
Samsung	Samsung ML-3471nd	ML-D3470A	4000	130	
Samsung	Samsung ML-3560	ML-3560DB	12000	400	
Samsung	Samsung ML-3561n	ML-3560DB	12000	400	
Samsung	Samsung ML-3561nd	ML-3560DB	12000	400	
Samsung	Samsung ML-4050n	ML-D4550A	10000	330	
Samsung	Samsung ML-4050n	ML-D4550B	20000	660	
Samsung	Samsung ML-4550	ML-D4550B	20000	660	
Samsung	Samsung ML-4550	ML-D4550A	10000	330	
Samsung	Samsung ML-4551	ML-D4550A	10000	330	
Samsung	Samsung ML-4551	ML-D4550B	20000	660	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Samsung	Samsung ML-4551nd	ML-D4550B	20000	660	
Samsung	Samsung ML-4551nd	ML-D4550A	10000	330	
Samsung	Samsung ML-6040	ML-6060D6	6000	200	
Samsung	Samsung ML-6060	ML-6060D6	6000	200	
Samsung	Samsung ML-6060n	ML-6060D6	6000	200	
Samsung	Samsung ML-6060s	ML-6060D6	6000	200	
Samsung	Samsung SCX-4016	SCX-4216D3	3000	100	
Samsung	Samsung SCX-4100	SCX-4100D3	3000	100	
Samsung	Samsung SCX-4116	SCX-4216D3	3000	100	
Samsung	Samsung SCX-4116d	SCX-4216D3	3000	100	
Samsung	Samsung SCX-4150	SCX-4100D3	3000	100	
Samsung	Samsung SCX-4200	SCX-4200A	3000	100	
Samsung	Samsung SCX-4216f	SCX-4216D3	3000	100	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Samsung	Samsung SCX-4220	SCX-4200A	3000	100	
Samsung	Samsung SCX-4321	ML-1610D3	3000	100	
Samsung	Samsung SCX-4321	SCX-4521D3	3000	100	
Samsung	Samsung SCX-4321F	SCX-4521D3	3000	100	
Samsung	Samsung SCX-4500	ML-D1630A	2000	80	
Samsung	Samsung SCX-4520	SCX-4720D5	5000	160	
Samsung	Samsung SCX-4520	SCX-4720D3	3000	100	
Samsung	Samsung SCX-4521	SCX-4521D3	3000	100	
Samsung	Samsung SCX-4521F	SCX-4521D3	3000	100	
Samsung	Samsung SCX-4521F	ML-1610D3	3000	100	
Samsung	Samsung SCX-4645	SCX-D6555A	25000	820	
Samsung	Samsung SCX-4720F	SCX-4720D5	5000	160	
Samsung	Samsung SCX-4720F	SCX-4720D3	3000	100	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Samsung	Samsung SCX-4720FN	SCX-4720D3	3000	100	
Samsung	Samsung SCX-4720FN	SCX-4720D5	5000	160	
Samsung	Samsung SCX-4725	SCX-D4725A	3000	100	
Samsung	Samsung SCX-5015	SCX-5312D6	6000	200	
Samsung	Samsung SCX-5112	SCX-5312D6	6000	200	
Samsung	Samsung SCX-5115	SCX-5312D6	6000	200	
Samsung	Samsung SCX-5312	SCX-5312D6	6000	200	
Samsung	Samsung SCX-5315	SCX-5312D6	6000	200	
Samsung	Samsung SCX-5330n	SCX-D5530A	4000	130	
Samsung	Samsung SCX-5330n	SCX-D5530B	8000	260	
Samsung	Samsung SCX-5530fn	SCX-D5530B	8000	260	
Samsung	Samsung SCX-5530fn	SCX-D5530A	4000	130	
Samsung	Samsung SCX-6120	SCX-6320D8	8000	260	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Samsung	Samsung SCX-6122fn	SCX-6320D8	8000	260	
Samsung	Samsung SCX-6220	SCX-6320D8	8000	260	
Samsung	Samsung SCX-6320	SCX-6320D8	8000	260	
Samsung	Samsung SCX-6322dn	SCX-6320D8	8000	260	
Samsung	Samsung SCX-6545n	SCX-D6555A	25000	820	
Samsung	Samsung SCX-6555n	SCX-D6555A	25000	820	
Samsung	Samsung SCX-6811	SCX-D6555A	25000	820	
Samsung	Samsung SF-560	SCX-4216D3	3000	100	
Samsung	Samsung SF-565P	SCX-4216D3	3000	100	
Samsung	Samsung SF-750	SCX-4216D3	3000	100	
Samsung	Samsung SF-755	SCX-4216D3	3000	100	
Samsung	Samsung SF-830	SCX-5312D6	6000	200	
Xerox	Xerox DocuPrint 4508	113R00296	5000	160	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Xerox	Xerox DocuPrint P1210	106R00442	6000	200	
Xerox	Xerox DocuPrint P8e	113R00296	5000	160	
Xerox	Xerox DocuPrint P8ex	113R00296	5000	160	
Xerox	Xerox Phaser 3100MFP	106R01378	3000	100	
Xerox	Xerox Phaser 3100MFP	106R01379	6000	200	
Xerox	Xerox Phaser 3110	109R00639	3000	100	
Xerox	Xerox Phaser 3115	109R00748	3000	100	
Xerox	Xerox Phaser 3115	109R00725	3000	100	
Xerox	Xerox Phaser 3116	109R00725	3000	100	
Xerox	Xerox Phaser 3116	109R00748	3000	100	
Xerox	Xerox Phaser 3117	106R01159	3000	100	
Xerox	Xerox Phaser 3120	109R00725	3000	100	
Xerox	Xerox Phaser 3121	109R00725	3000	100	



<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Xerox	Xerox Phaser 3122	106R01159	3000	100	
Xerox	Xerox Phaser 3124	106R01159	3000	100	
Xerox	Xerox Phaser 3125	106R01159	3000	100	
Xerox	Xerox Phaser 3125n	106R01159	3000	100	
Xerox	Xerox Phaser 3130	109R00725	3000	100	
Xerox	Xerox Phaser 3131	109R00725	3000	100	
Xerox	Xerox Phaser 3140	108R00908	1500	60	
Xerox	Xerox Phaser 3140	108R00909	2500	85	
Xerox	Xerox Phaser 3150	109R00746	3500	115	
Xerox	Xerox Phaser 3150	109R00747	5000	160	
Xerox	Xerox Phaser 3155	108R00909	2500	85	
Xerox	Xerox Phaser 3155	108R00908	1500	60	
Xerox	Xerox Phaser 3160	108R00908	1500	60	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Xerox	Xerox Phaser 3160	108R00909	2500	85	
Xerox	Xerox Phaser 3160B	108R00908	1500	60	
Xerox	Xerox Phaser 3160B	108R00909	2500	85	
Xerox	Xerox Phaser 3160N	108R00909	2500	85	
Xerox	Xerox Phaser 3160N	108R00908	1500	60	
Xerox	Xerox Phaser 3200MFP	113R00735	2000	80	
Xerox	Xerox Phaser 3200MFP	113R00730	3000	100	
Xerox	Xerox Phaser 3210	109R00639	3000	100	
Xerox	Xerox Phaser 3250	106R01373	3500	115	
Xerox	Xerox Phaser 3250	106R01374	5000	160	
Xerox	Xerox Phaser 3250D	106R01374	5000	160	
Xerox	Xerox Phaser 3250D	106R01373	3500	115	
Xerox	Xerox Phaser 3250DN	106R01373	3500	115	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Xerox	Xerox Phaser 3250DN	106R01374	5000	160	
Xerox	Xerox Phaser 3300MFP	106R01411	4000	130	
Xerox	Xerox Phaser 3300MFP	106R01412	8000	260	
Xerox	Xerox Phaser 3330	106R03621	8500	280	
Xerox	Xerox Phaser 3330	106R03623	15000	480	
Xerox	Xerox Phaser 3330DNI	106R03623	15000	480	
Xerox	Xerox Phaser 3330DNI	106R03621	8500	280	
Xerox	Xerox Phaser 3420	106R01033	5000	160	
Xerox	Xerox Phaser 3420	106R01034	10000	330	
Xerox	Xerox Phaser 3425	106R01034	10000	330	
Xerox	Xerox Phaser 3425	106R01033	5000	160	
Xerox	Xerox Phaser 3428D	106R01246	8200	270	
Xerox	Xerox Phaser 3428DN	106R01246	8200	270	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Xerox	Xerox Phaser 3435	106R01415	10000	330	
Xerox	Xerox Phaser 3435DN	106R01415	10000	330	
Xerox	Xerox Phaser 3450	106R00687	5000	160	
Xerox	Xerox Phaser 3450D	106R00687	5000	160	
Xerox	Xerox Phaser 3500B	106R01148	6000	200	
Xerox	Xerox Phaser 3500DN	106R01148	6000	200	
Xerox	Xerox Phaser 3500N	106R01148	6000	200	
Xerox	Xerox Phaser PE114e	109R00725	3000	100	
Xerox	Xerox Phaser PE16e	109R00725	3000	100	
Xerox	Xerox WorkCentre 3119	013R00625	3000	100	
Xerox	Xerox WorkCentre 3119v	013R00625	3000	100	
Xerox	Xerox WorkCentre 312	106R00586	6000	200	
Xerox	Xerox WorkCentre 3210	106R01487	4100	135	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Xerox	Xerox WorkCentre 3210	106R01485	2000	80	
Xerox	Xerox WorkCentre 3210N	106R01485	2000	80	
Xerox	Xerox WorkCentre 3210N	106R01487	4100	135	
Xerox	Xerox WorkCentre 3220	106R01487	4100	135	
Xerox	Xerox WorkCentre 3220	106R01485	2000	80	
Xerox	Xerox WorkCentre 3220DN	106R01485	2000	80	
Xerox	Xerox WorkCentre 3220DN	106R01487	4100	135	
Xerox	Xerox WorkCentre 3335	106R03621	8500	280	
Xerox	Xerox WorkCentre 3335	106R03623	15000	480	
Xerox	Xerox WorkCentre 3335DNI	106R03623	15000	480	
Xerox	Xerox WorkCentre 3335DNI	106R03621	8500	280	
Xerox	Xerox WorkCentre 3345	106R03621	8500	280	
Xerox	Xerox WorkCentre 3345	106R03623	15000	480	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Xerox	Xerox WorkCentre 3345DNI	106R03623	15000	480	
Xerox	Xerox WorkCentre 3345DNI	106R03621	8500	280	
Xerox	Xerox WorkCentre 3550	106R01529	5000	160	
Xerox	Xerox WorkCentre 3550	106R01531	11000	360	
Xerox	Xerox WorkCentre 3550X	106R01531	11000	360	
Xerox	Xerox WorkCentre 3550X	106R01529	5000	160	
Xerox	Xerox WorkCentre 3600	106R01370	7000	230	
Xerox	Xerox WorkCentre 3600	106R01371	14000	460	
Xerox	Xerox WorkCentre 3600	106R01372	20000	660	
Xerox	Xerox WorkCentre 385	113R00296	5000	160	
Xerox	Xerox WorkCentre B205	106R04348	3000	100	
Xerox	Xerox WorkCentre B210	106R04348	3000	100	
Xerox	Xerox WorkCentre B215	106R04348	3000	100	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Xerox	Xerox WorkCentre M15	106R00586	6000	200	
Xerox	Xerox WorkCentre M15i	106R00586	6000	200	
Xerox	Xerox WorkCentre M20	106R01048	8000	260	
Xerox	Xerox WorkCentre M20i	106R01048	8000	260	
Xerox	Xerox WorkCentre PE114	013R00607	3000	100	
Xerox	Xerox WorkCentre PE120	013R00606	5000	160	
Xerox	Xerox WorkCentre PE120i	013R00606	5000	160	
Xerox	Xerox WorkCentre PE16	113R00667	3500	115	
Xerox	Xerox WorkCentre PE220	013R00621	3000	100	
Xerox	Xerox WorkCentre Pro 412	106R00586	6000	200	