



# CS-TBR-100

## Тонер Cactus CS-TBR-100

Бренд	Принтер	Картридж	Ресурс	Вес заправки	Примечание
Brother	Brother DCP-1510R	TN-1075	1000	40	
Brother	Brother DCP-1512R	TN-1075	1000	40	
Brother	Brother DCP-1610WR	TN-1075	1000	40	
Brother	Brother DCP-1612WR	TN-1075	1000	40	
Brother	Brother DCP-1910W	TN-1075	1000	40	
Brother	Brother DCP-6600DW	TN-3480	8000	260	
Brother	Brother DCP-6600DW	TN-3430	3000	100	
Brother	Brother DCP-6600DW	TN-3520	20000	660	
Brother	Brother DCP-7010R	TN-2075	2500	85	
Brother	Brother DCP-7020	TN-2075	2500	85	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother DCP-7025R	TN-2075	2500	85	
Brother	Brother DCP-7030R	TN-2135	1500	60	
Brother	Brother DCP-7030R	TN-2175	2600	85	
Brother	Brother DCP-7032R	TN-2175	2600	85	
Brother	Brother DCP-7032R	TN-2135	1500	60	
Brother	Brother DCP-7040R	TN-2135	1500	60	
Brother	Brother DCP-7040R	TN-2175	2600	85	
Brother	Brother DCP-7045NR	TN-2175	2600	85	
Brother	Brother DCP-7045NR	TN-2135	1500	60	
Brother	Brother DCP-7055	TN-2235	1200	50	
Brother	Brother DCP-7055	TN-2275	2600	85	
Brother	Brother DCP-7055R	TN-2080	700	30	
Brother	Brother DCP-7057R	TN-2090	1000	40	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother DCP-7060DR	TN-2235	1200	50	
Brother	Brother DCP-7060DR	TN-2275	2600	85	
Brother	Brother DCP-7065DNR	TN-2275	2600	85	
Brother	Brother DCP-7065DNR	TN-2235	1200	50	
Brother	Brother DCP-7070DWR	TN-2235	1200	50	
Brother	Brother DCP-7070DWR	TN-2275	2600	85	
Brother	Brother DCP-7075WR	TN-2090	1000	40	
Brother	Brother DCP-8020	TN-7600	6500	210	
Brother	Brother DCP-8025D	TN-7600	6500	210	
Brother	Brother DCP-8025DN	TN-7600	6500	210	
Brother	Brother DCP-8040D	TN-3030	3500	110	
Brother	Brother DCP-8040D	TN-3060	6700	220	
Brother	Brother DCP-8045D	TN-3060	6700	220	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother DCP-8045D	TN-3030	3500	110	
Brother	Brother DCP-8045DN	TN-3030	3500	110	
Brother	Brother DCP-8045DN	TN-3060	6700	220	
Brother	Brother DCP-8060	TN-3130	3500	110	
Brother	Brother DCP-8060	TN-3170	7000	230	
Brother	Brother DCP-8065DN	TN-3170	7000	230	
Brother	Brother DCP-8065DN	TN-3130	3500	110	
Brother	Brother DCP-8070D	TN-3230	3000	100	
Brother	Brother DCP-8070D	TN-3280	8000	260	
Brother	Brother DCP-8085DN	TN-3280	8000	260	
Brother	Brother DCP-8085DN	TN-3230	3000	100	
Brother	Brother DCP-8110	TN-3330	3000	100	
Brother	Brother DCP-8110	TN-3380	8000	260	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother DCP-8250	TN-3380	8000	260	
Brother	Brother DCP-8250	TN-3390	12000	400	
Brother	Brother DCP-8250	TN-3330	3000	100	
Brother	Brother DCP-L2500DR	TN-2335	1200	50	
Brother	Brother DCP-L2500DR	TN-2375	2600	85	
Brother	Brother DCP-L2520DWR	TN-2375	2600	85	
Brother	Brother DCP-L2520DWR	TN-2335	1200	50	
Brother	Brother DCP-L2540DWR	TN-2335	1200	50	
Brother	Brother DCP-L2540DWR	TN-2375	2600	85	
Brother	Brother DCP-L2560DWR	TN-2375	2600	85	
Brother	Brother DCP-L2560DWR	TN-2335	1200	50	
Brother	Brother DCP-L5500DN	TN-3430	3000	100	
Brother	Brother DCP-L5500DN	TN-3480	8000	260	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother FAX-2820R	TN-2075	2500	85	
Brother	Brother FAX-2825R	TN-2075	2500	85	
Brother	Brother FAX-2845R	TN-2275	2600	85	
Brother	Brother FAX-2845R	TN-2235	1200	50	
Brother	Brother FAX-2850	TN-8000	2200	75	
Brother	Brother FAX-2920R	TN-2075	2500	85	
Brother	Brother FAX-2940R	TN-2235	1200	50	
Brother	Brother FAX-2940R	TN-2275	2600	85	
Brother	Brother FAX-2990R	TN-2075	2500	85	
Brother	Brother FAX-4750	TN-6300	3000	100	
Brother	Brother FAX-4750	TN-6600	6000	200	
Brother	Brother FAX-5750	TN-6600	6000	200	
Brother	Brother FAX-5750	TN-6300	3000	100	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother FAX-8070P	TN-8000	2200	75	
Brother	Brother FAX-8350P	TN-6600	6000	200	
Brother	Brother FAX-8350P	TN-6300	3000	100	
Brother	Brother FAX-8360P	TN-6300	3000	100	
Brother	Brother FAX-8360P	TN-6600	6000	200	
Brother	Brother FAX-8750P	TN-6600	6000	200	
Brother	Brother FAX-8750P	TN-6300	3000	100	
Brother	Brother HL-1030	TN-6300	3000	100	
Brother	Brother HL-1030	TN-6600	6000	200	
Brother	Brother HL-1110R	TN-1075	1000	40	
Brother	Brother HL-1111R	TN-1075	1000	40	
Brother	Brother HL-1112R	TN-1075	1000	40	
Brother	Brother HL-1210WR	TN-1075	1000	40	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother HL-1212WR	TN-1075	1000	40	
Brother	Brother HL-1230	TN-6300	3000	100	
Brother	Brother HL-1230	TN-6600	6000	200	
Brother	Brother HL-1240	TN-6600	6000	200	
Brother	Brother HL-1240	TN-6300	3000	100	
Brother	Brother HL-1250	TN-6300	3000	100	
Brother	Brother HL-1250	TN-6600	6000	200	
Brother	Brother HL-1260e	TN-7600	6500	210	
Brother	Brother HL-1270N	TN-6600	6000	200	
Brother	Brother HL-1270N	TN-6300	3000	100	
Brother	Brother HL-1430	TN-6300	3000	100	
Brother	Brother HL-1430	TN-6600	6000	200	
Brother	Brother HL-1440	TN-6600	6000	200	



<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother HL-1440	TN-6300	3000	100	
Brother	Brother HL-1450	TN-6300	3000	100	
Brother	Brother HL-1450	TN-6600	6000	200	
Brother	Brother HL-1470N	TN-6600	6000	200	
Brother	Brother HL-1470N	TN-6300	3000	100	
Brother	Brother HL-1650	TN-7600	6500	210	
Brother	Brother HL-1670N	TN-7600	6500	210	
Brother	Brother HL-1850	TN-7600	6500	210	
Brother	Brother HL-1870N	TN-7600	6500	210	
Brother	Brother HL-2030R	TN-2075	2500	85	
Brother	Brother HL-2035R	TN-2085	1500	60	
Brother	Brother HL-2040R	TN-2075	2500	85	
Brother	Brother HL-2070NR	TN-2075	2500	85	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother HL-2130R	TN-2080	700	30	
Brother	Brother HL-2130R	TN-2275	2600	85	
Brother	Brother HL-2130R	TN-2235	1200	50	
Brother	Brother HL-2132R	TN-2235	1200	50	
Brother	Brother HL-2132R	TN-2275	2600	85	
Brother	Brother HL-2132R	TN-2090	1000	40	
Brother	Brother HL-2140R	TN-2175	2600	85	
Brother	Brother HL-2140R	TN-2135	1500	60	
Brother	Brother HL-2142R	TN-2135	1500	60	
Brother	Brother HL-2142R	TN-2175	2600	85	
Brother	Brother HL-2150NR	TN-2175	2600	85	
Brother	Brother HL-2150NR	TN-2135	1500	60	
Brother	Brother HL-2170WR	TN-2135	1500	60	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother HL-2170WR	TN-2175	2600	85	
Brother	Brother HL-2200R	TN-2235	1200	50	
Brother	Brother HL-2200R	TN-2275	2600	85	
Brother	Brother HL-2210R	TN-2275	2600	85	
Brother	Brother HL-2210R	TN-2235	1200	50	
Brother	Brother HL-2225R	TN-2235	1200	50	
Brother	Brother HL-2225R	TN-2275	2600	85	
Brother	Brother HL-2230R	TN-2275	2600	85	
Brother	Brother HL-2230R	TN-2235	1200	50	
Brother	Brother HL-2235R	TN-2275	2600	85	
Brother	Brother HL-2235R	TN-2235	1200	50	
Brother	Brother HL-2240DR	TN-2235	1200	50	
Brother	Brother HL-2240DR	TN-2275	2600	85	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother HL-2240R	TN-2275	2600	85	
Brother	Brother HL-2240R	TN-2235	1200	50	
Brother	Brother HL-2250DNR	TN-2235	1200	50	
Brother	Brother HL-2250DNR	TN-2275	2600	85	
Brother	Brother HL-2260R	TN-2275	2600	85	
Brother	Brother HL-2260R	TN-2235	1200	50	
Brother	Brother HL-2270R	TN-2235	1200	50	
Brother	Brother HL-2270R	TN-2275	2600	85	
Brother	Brother HL-2365DWR	TN-2335	1200	50	
Brother	Brother HL-2365DWR	TN-2375	2600	85	
Brother	Brother HL-5030	TN-7600	6500	210	
Brother	Brother HL-5040	TN-7600	6500	210	
Brother	Brother HL-5050	TN-7600	6500	210	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother HL-5070	TN-7600	6500	210	
Brother	Brother HL-5130	TN-3060	6700	220	
Brother	Brother HL-5130	TN-3030	3500	110	
Brother	Brother HL-5140	TN-3030	3500	110	
Brother	Brother HL-5140	TN-3060	6700	220	
Brother	Brother HL-5140D	TN-3060	6700	220	
Brother	Brother HL-5140D	TN-3030	3500	110	
Brother	Brother HL-5150D	TN-3030	3500	110	
Brother	Brother HL-5150D	TN-3060	6700	220	
Brother	Brother HL-5170DN	TN-3060	6700	220	
Brother	Brother HL-5170DN	TN-3030	3500	110	
Brother	Brother HL-5240	TN-3170	7000	230	
Brother	Brother HL-5240	TN-3130	3500	110	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother HL-5250DN	TN-3130	3500	110	
Brother	Brother HL-5250DN	TN-3170	7000	230	
Brother	Brother HL-5270DN	TN-3170	7000	230	
Brother	Brother HL-5270DN	TN-3130	3500	110	
Brother	Brother HL-5280DW	TN-3130	3500	110	
Brother	Brother HL-5280DW	TN-3170	7000	230	
Brother	Brother HL-5340D	TN-3280	8000	260	
Brother	Brother HL-5340D	TN-3230	3000	100	
Brother	Brother HL-5350DN	TN-3230	3000	100	
Brother	Brother HL-5350DN	TN-3280	8000	260	
Brother	Brother HL-5370DW	TN-3280	8000	260	
Brother	Brother HL-5370DW	TN-3230	3000	100	
Brother	Brother HL-5380DN	TN-3230	3000	100	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother HL-5380DN	TN-3280	8000	260	
Brother	Brother HL-5440D	TN-3380	8000	260	
Brother	Brother HL-5440D	TN-3330	3000	100	
Brother	Brother HL-5450DN	TN-3330	3000	100	
Brother	Brother HL-5450DN	TN-3380	8000	260	
Brother	Brother HL-5450DNT	TN-3380	8000	260	
Brother	Brother HL-5450DNT	TN-3330	3000	100	
Brother	Brother HL-5470DW	TN-3330	3000	100	
Brother	Brother HL-5470DW	TN-3380	8000	260	
Brother	Brother HL-6180DW	TN-3380	8000	260	
Brother	Brother HL-6180DW	TN-3330	3000	100	
Brother	Brother HL-6180DW	TN-3390	12000	400	
Brother	Brother HL-6180DWT	TN-3390	12000	400	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother HL-6180DWT	TN-3330	3000	100	
Brother	Brother HL-6180DWT	TN-3380	8000	260	
Brother	Brother HL-L2300DR	TN-2375	2600	85	
Brother	Brother HL-L2300DR	TN-2335	1200	50	
Brother	Brother HL-L2340DWR	TN-2335	1200	50	
Brother	Brother HL-L2340DWR	TN-2375	2600	85	
Brother	Brother HL-L2360DNR	TN-2375	2600	85	
Brother	Brother HL-L2360DNR	TN-2335	1200	50	
Brother	Brother HL-L2380	TN-2335	1200	50	
Brother	Brother HL-L2380	TN-2375	2600	85	
Brother	Brother HL-L5000D	TN-3430	3000	100	
Brother	Brother HL-L5000D	TN-3480	8000	260	
Brother	Brother HL-L5100DN	TN-3480	8000	260	



<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother HL-L5100DN	TN-3430	3000	100	
Brother	Brother HL-L5100DNT	TN-3430	3000	100	
Brother	Brother HL-L5100DNT	TN-3480	8000	260	
Brother	Brother HL-L5200DW	TN-3480	8000	260	
Brother	Brother HL-L5200DW	TN-3430	3000	100	
Brother	Brother HL-L6250DN	TN-3430	3000	100	
Brother	Brother HL-L6250DN	TN-3480	8000	260	
Brother	Brother HL-L6300DN	TN-3480	8000	260	
Brother	Brother HL-L6300DN	TN-3430	3000	100	
Brother	Brother HL-L6300DWT	TN-3430	3000	100	
Brother	Brother HL-L6300DWT	TN-3480	8000	260	
Brother	Brother HL-L6400DW	TN-3480	8000	260	
Brother	Brother HL-L6400DW	TN-3520	20000	660	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother HL-L6400DW	TN-3430	3000	100	
Brother	Brother HL-L6400DWT	TN-3430	3000	100	
Brother	Brother HL-L6400DWT	TN-3520	20000	660	
Brother	Brother HL-L6400DWT	TN-3480	8000	260	
Brother	Brother HL-P2500	TN-6300	3000	100	
Brother	Brother HL-P2500	TN-6600	6000	200	
Brother	Brother IntelliFAX-2800	TN-8000	2200	75	
Brother	Brother IntelliFAX-2900	TN-8000	2200	75	
Brother	Brother IntelliFAX-3800	TN-8000	2200	75	
Brother	Brother IntelliFAX-4100	TN-6600	6000	200	
Brother	Brother IntelliFAX-4100	TN-6300	3000	100	
Brother	Brother IntelliFAX-4750	TN-6300	3000	100	
Brother	Brother IntelliFAX-4750	TN-6600	6000	200	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother IntelliFAX-5750	TN-6600	6000	200	
Brother	Brother IntelliFAX-5750	TN-6300	3000	100	
Brother	Brother MFC-1810R	TN-1075	1000	40	
Brother	Brother MFC-1815R	TN-1075	1000	40	
Brother	Brother MFC-1912WR	TN-1075	1000	40	
Brother	Brother MFC-2700DNR	TN-2335	1200	50	
Brother	Brother MFC-2700DNR	TN-2375	2600	85	
Brother	Brother MFC-4800	TN-8000	2200	75	
Brother	Brother MFC-6800	TN-8000	2200	75	
Brother	Brother MFC-7220	TN-2075	2500	85	
Brother	Brother MFC-7225	TN-2075	2500	85	
Brother	Brother MFC-7320R	TN-2175	2600	85	
Brother	Brother MFC-7320R	TN-2135	1500	60	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother MFC-7360NR	TN-2235	1200	50	
Brother	Brother MFC-7360NR	TN-2275	2600	85	
Brother	Brother MFC-7420	TN-2075	2500	85	
Brother	Brother MFC-7440NR	TN-2135	1500	60	
Brother	Brother MFC-7440NR	TN-2175	2600	85	
Brother	Brother MFC-7820	TN-2075	2500	85	
Brother	Brother MFC-7840WR	TN-2175	2600	85	
Brother	Brother MFC-7840WR	TN-2135	1500	60	
Brother	Brother MFC-7860DWR	TN-2235	1200	50	
Brother	Brother MFC-7860DWR	TN-2275	2600	85	
Brother	Brother MFC-8220	TN-3030	3500	110	
Brother	Brother MFC-8220	TN-3060	6700	220	
Brother	Brother MFC-8350	TN-6300	3000	100	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother MFC-8350	TN-6600	6000	200	
Brother	Brother MFC-8370DN	TN-3230	3000	100	
Brother	Brother MFC-8370DN	TN-3280	8000	260	
Brother	Brother MFC-8420	TN-7600	6500	210	
Brother	Brother MFC-8440D	TN-3030	3500	110	
Brother	Brother MFC-8440D	TN-3060	6700	220	
Brother	Brother MFC-8460N	TN-3130	3500	110	
Brother	Brother MFC-8460N	TN-3170	7000	230	
Brother	Brother MFC-8510DN	TN-3330	3000	100	
Brother	Brother MFC-8510DN	TN-3380	8000	260	
Brother	Brother MFC-8520DN	TN-3380	8000	260	
Brother	Brother MFC-8520DN	TN-3330	3000	100	
Brother	Brother MFC-8710DN	TN-3330	3000	100	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother MFC-8710DN	TN-3380	8000	260	
Brother	Brother MFC-8750	TN-6300	3000	100	
Brother	Brother MFC-8750	TN-6600	6000	200	
Brother	Brother MFC-8820D	TN-7600	6500	210	
Brother	Brother MFC-8820DN	TN-7600	6500	210	
Brother	Brother MFC-8840DN	TN-3030	3500	110	
Brother	Brother MFC-8840DN	TN-3060	6700	220	
Brother	Brother MFC-8860DN	TN-3170	7000	230	
Brother	Brother MFC-8860DN	TN-3130	3500	110	
Brother	Brother MFC-8870DW	TN-3170	7000	230	
Brother	Brother MFC-8870DW	TN-3130	3500	110	
Brother	Brother MFC-8880DN	TN-3230	3000	100	
Brother	Brother MFC-8880DN	TN-3280	8000	260	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother MFC-8890DN	TN-3280	8000	260	
Brother	Brother MFC-8890DN	TN-3230	3000	100	
Brother	Brother MFC-8910DN	TN-3330	3000	100	
Brother	Brother MFC-8910DN	TN-3380	8000	260	
Brother	Brother MFC-8950DW	TN-3380	8000	260	
Brother	Brother MFC-8950DW	TN-3390	12000	400	
Brother	Brother MFC-8950DW	TN-3330	3000	100	
Brother	Brother MFC-9030	TN-8000	2200	75	
Brother	Brother MFC-9070	TN-8000	2200	75	
Brother	Brother MFC-9160	TN-8000	2200	75	
Brother	Brother MFC-9180	TN-8000	2200	75	
Brother	Brother MFC-9600	TN-6300	3000	100	
Brother	Brother MFC-9600	TN-6600	6000	200	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother MFC-9650	TN-6600	6000	200	
Brother	Brother MFC-9650	TN-6300	3000	100	
Brother	Brother MFC-9660	TN-6300	3000	100	
Brother	Brother MFC-9660	TN-6600	6000	200	
Brother	Brother MFC-9750	TN-6600	6000	200	
Brother	Brother MFC-9750	TN-6300	3000	100	
Brother	Brother MFC-9760	TN-6300	3000	100	
Brother	Brother MFC-9760	TN-6600	6000	200	
Brother	Brother MFC-9850	TN-6600	6000	200	
Brother	Brother MFC-9850	TN-6300	3000	100	
Brother	Brother MFC-9860	TN-6300	3000	100	
Brother	Brother MFC-9860	TN-6600	6000	200	
Brother	Brother MFC-9870	TN-6600	6000	200	



<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother MFC-9870	TN-6300	3000	100	
Brother	Brother MFC-9880	TN-6300	3000	100	
Brother	Brother MFC-9880	TN-6600	6000	200	
Brother	Brother MFC-L2700DWR	TN-2335	1200	50	
Brother	Brother MFC-L2700DWR	TN-2375	2600	85	
Brother	Brother MFC-L2720DWR	TN-2375	2600	85	
Brother	Brother MFC-L2720DWR	TN-2335	1200	50	
Brother	Brother MFC-L2740DWR	TN-2335	1200	50	
Brother	Brother MFC-L2740DWR	TN-2375	2600	85	
Brother	Brother MFC-L5700DN	TN-3430	3000	100	
Brother	Brother MFC-L5700DN	TN-3480	8000	260	
Brother	Brother MFC-L5750DW	TN-3480	8000	260	
Brother	Brother MFC-L5750DW	TN-3430	3000	100	

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother MFC-L6800DW	TN-3430	3000	100	
Brother	Brother MFC-L6800DW	TN-3480	8000	260	
Brother	Brother MFC-L6800DW	TN-3520	20000	660	
Brother	Brother MFC-L6800DWT	TN-3520	20000	660	
Brother	Brother MFC-L6800DWT	TN-3480	8000	260	
Brother	Brother MFC-L6800DWT	TN-3430	3000	100	
Brother	Brother MFC-L6900DW	TN-3430	3000	100	
Brother	Brother MFC-L6900DW	TN-3480	8000	260	
Brother	Brother MFC-L6900DW	TN-3520	20000	660	
Brother	Brother MFC-L6900DWT	TN-3520	20000	660	
Brother	Brother MFC-L6900DWT	TN-3480	8000	260	
Brother	Brother MFC-L6900DWT	TN-3430	3000	100	
Brother	Brother MFC8440DN	TN-3060	6700	220	

---

<b>Бренд</b>	<b>Принтер</b>	<b>Картридж</b>	<b>Ресурс</b>	<b>Вес заправки</b>	<b>Примечание</b>
Brother	Brother MFC8440DN	TN-3030	3500	110	

---